

Evolve Crystal Right



Evolve Crystal Right Filter

OPERATING MANUAL

OTHER LANGUAGES AVAILABLE



NL/ Scan bovenstaande QR code om de Nederlandstalige handleiding te raadplegen.



FR/ Scannez le code QR ci-dessus pour consulter la notice en Français.



DE/ Scannen Sie den obigen QR-Code ein, um das Handbuch in deutscher Sprache zu konsultieren.

TABLE OF CONTENTS

1. INTRODUCTION	4
2. PRESENTATION	5
3. INSTALLATION	8
4. PROGRAMMING	14
5. COMMISSIONING	20
6. MAINTENANCE	22
7. TROUBLESHOOTING	25
8. REPLACEMENT PARTS & INSTALLATION FITTINGS	32
9. CERTIFICATION	40
10. QUICK REFERENCE GUIDE	41

1. INTRODUCTION

We would like to thank you for acquiring the Evolve Crystal Right filter, an all-in-one solution for the treatment of your city water & well water.


You have made an excellent choice that will allow you to benefit from the highest quality of water in the future.

The Evolve Crystal Right filter is delivered with a by-pass. Please check the unit carefully, in the presence of the delivery man, to ensure you that it was not damaged during transport.

Before starting up your device, please read this manual carefully. Proper installation guarantees a long service life and high performance of your unit. The packaging can be fully recycled, please dispose of it in a suitable place.

Join our mission.
Make water count.

2. PRESENTATION



2.1. SPECIFICATIONS EVOLVE CRYSTAL RIGHT FILTER

MODEL	EV - 28,3L	EV - 42,5L	EV - 71,8L	EV - 99L
Capacity				
CR100	40 m ³ dH 74 m ³ °F	75 m ³ dH 130 m ³ °F	120 m ³ dH 215 m ³ °F	165 m ³ dH 295 m ³ °F
CR200	70 m ³ dH 125 m ³ °F	115 m ³ dH 205 m ³ °F	175 m ³ dH 310 m ³ °F	200 m ³ dH 360 m ³ °F
Control System	Evolve 1"	Evolve 1"	Evolve 1"	Evolve 1"
Regeneration Type	Down Flow	Down Flow	Down Flow	Down Flow
Regeneration Mode	Delayed regeneration	Delayed regeneration	Delayed regeneration	Delayed regeneration
Tank size	10x44	10x54	13x54	14x65
Brine tank size	130L	130L	130L	130L
Crystal Right Quantity	28,3L	42,5L	71,8L	99L
Nominal Flow	1,5 m ³ /h	1,5 m ³ /h	2 m ³ /h	2,5 m ³ /h
Salt Used Per Regeneration (100g salt/L CR)	4kg	5,25kg	7,5kg	10kg
Plumbing Connections	1"	1"	1"	1"
Electrical Rating	220 - 240V 50/60 Hz	220 - 240V 50/60 Hz	220 - 240V 50/60 Hz	220 - 240V 50/60 Hz
Water Supply	City & well water	City & well water	City & well water	City & well water
Water temperature	0,5 ~ 37,7 °C	0,5 ~ 37,7 °C	0,5 ~ 37,7 °C	0,5 ~ 37,7 °C
Operating Pressure	1,7 ~ 6,8 bar	1,7 ~ 6,8 bar	1,7 ~ 6,8 bar	1,7 ~ 6,8 bar
Dimensions mm				
Size Valve	292,4 x 213,4	292,4 x 213,4	292,4 x 213,4	292,4 x 213,4
Size tank	254 x 1117,6	254 x 1371,6	330,2 x 1371,6	355,6 x 1651
Size Brine tank	457,2 x 838,2	457,2 x 838,2	457,2 x 838,2	457,2 x 1016

* Flow rates and capacities may vary depending on water quality

Bigger units (311L, 538L, 707L) available on request

Join our mission.
Make water count.

MODEL	EV - 127L	EV - 170L	EV - 198L
Capacity			
CR100	215 m ³ dH 380 m ³ °F	285 m ³ dH 510 m ³ °F	335 m ³ dH 590 m ³ °F
CR200	270 m ³ dH 485 m ³ °F	380 m ³ dH 680 m ³ °F	444 m ³ dH 790 m ³ °F
Control System	Evolve 1"	Evolve 1"	Evolve 1"
Regeneration Type	Down Flow	Down Flow	Down Flow
Regeneration Mode	Delayed regeneration	Delayed regeneration	Delayed regeneration
Tank size	16x65	18x65	21x60
Brine tank size	200L	200L	200L
Crystal Right Quantity	127L	170L	198L
Nominal Flow	3 m ³ /h	4 m ³ /h	5 m ³ /h
Salt Used Per Regeneration (100g salt/L CR)	13kg	17kg	20kg
Plumbing Connections	1"	1,25"	1,25"
Electrical Rating	220 - 240V 50/60 Hz	220 - 240V 50/60 Hz	220 - 240V 50/60 Hz
Water Supply	City & well water	City & well water	City & well water
Water temperature	0,5 ~ 37,7 °C	0,5 ~ 37,7 °C	0,5 ~ 37,7 °C
Operating Pressure	1,7 ~ 6,8 bar	1,7 ~ 6,8 bar	1,7 ~ 6,8 bar
Dimensions mm			
Size Valve	292,4 x 213,4	292,4 x 213,4	292,4 x 213,4
Size tank	406,4 x 1651	457,2 x 1651	533,4 x 1524
Size Brine tank	457,2 x 1016	457,2 x 1016	457,2 x 1016

* Flow rates and capacities may vary depending on water quality

Bigger units (311L, 538L, 707L) available on request

3. INSTALLATION

3.1. PRE-INSTALLATION INSTRUCTIONS

The manufacturer has preset the water treatment unit's sequence of cycles, cycle times, salt dose, exchange capacity and salt dose refill time.

The dealer should...

- Read this page and guide the installer regarding hardness, day override, time of regeneration, service alarm, and buzzer alarm settings prior to installation.

The installer should...

- Program installer settings including hardness, day override, time of regeneration, service alarms, and buzzer alarm.
- Read Operating Displays and Maintenance section.
- Set the time of day.
- Read Power Loss and Error Display section.
- Ensure that system and installation are in compliance with all state and local laws and regulations.

The homeowner should...

- Read Programming Procedures section.

- Read Operating Displays and Maintenance section.

3.1.1 General operating displays & navigation

During normal operation, the default user displays are “time of day” and “liters per minute”. Flow rate, vacation mode, capacity remaining, and days to a regeneration are optional displays. For more explanation, consult the “operating displays and maintenance section”. Pressing the **NEXT** button on a general operating screen will cycle through the available operating displays.

In any screen other than a general operating display, the **NEXT** button will proceed to the next step, the **REGEN** button will return to a previous step, and the **CLOCK** button will return to the general operating displays. Any changes made prior to the exit will be incorporated. If no buttons are pressed within five minutes, the display will return to the general operating displays.

3.1.2 Double regeneration

Two generations within 24 hours are possible with a return to the preset program. To initiate a double regeneration:

Join our mission.
Make water count.

1. Press the **REGEN** button once.
“REGEN TODAY” will flash on the display.
2. Press and hold the **REGEN** button for three seconds until a regeneration begins.

Once the valve has completed the immediate regeneration, the valve will regenerate once more during the preset time.

3.2. BYPASS VALVE

The bypass valve is typically used to isolate the control valve from the plumbing system's water pressure in order to perform control valve repairs or maintenance. The 1" full flow bypass valve incorporates four positions, including a diagnostic position that allows a service technician to have pressure to test a system while providing untreated bypass water to the building. Be sure to install bypass valve onto main control valve before beginning plumbing or make provisions in the plumbing system for a bypass. The bypass body and rotors are glass-filled Noryl® and the nuts and caps are glass-filled polypropylene. All seals are self-lubricating EPDM to help prevent valve seizing after long periods of non-use. Internal “O” Rings can easily be replaced if service is required.

The bypass consists of two interchangeable plug valves that are





operated independently by red arrow shaped handles. The handles identify the direction of flow. The plug valves enable the bypass valve to operate in four positions.

1. Normal operation position: The inlet and outlet handles point in the direction of flow indicated by the engraved arrows on the control valve. Water flows through the control valve for normal operation of a water softener or filter. During the regeneration cycle this position provides regeneration water to the unit, while also providing untreated water to the distribution system (**Fig. 1**).

2. Bypass position: The inlet and outlet handles point to the center of the bypass. The system is isolated from the water pressure in the plumbing system. Untreated water is supplied to the building (**Fig. 2**).

3. Diagnostic position: The inlet handle points toward the control valve and the outlet handle points to the center of bypass valve. Untreated supply water is allowed to flow to the system and to the building, while not allowing water to exit from the system to the building (**Fig. 3**). This allows the service technician to test the unit and perform other functions without disrupting the water going to the building.

NOTE: The system must be rinsed before returning the bypass valve to the normal position.



4. Shut off position: The inlet handle points to the center of the bypass valve and the outlet handle points away from the control valve. The water is shut off to the building. The water treatment system will depressurize upon opening a tap in the building. A negative pressure in the building combined with the unit being in regeneration could cause a siphoning to the building. If water is available on the outlet side of the unit, it is an indication of water bypassing the system (Fig. 4) (i.e. a plumbing cross-connection somewhere in the building).

3.3. PHYSICAL INSTALLATION

3.3.1 General installation & service warnings

The control valve, fittings and/or bypass are designed to accommodate minor plumbing misalignments. There is a small amount of “give” to properly connect the piping, but the water

treatment unit is not designed to support the weight of the plumbing.

Do not use Vaseline, oils, other hydrocarbon lubricants, or spray silicone anywhere. A silicone lubricant may be used on black “O” Rings, but is not necessary. **Avoid any type of lubricants, including silicone, on red or clear lip seals.**



Do not use pipe dope or other sealants on threads. Teflon® tape must be used on the threads of the 1” BSPT inlet and outlet, the brine line connection at the control valve, and on the threads for the drain line connection. Teflon® tape is not used on the nut connections or caps because “O” Ring seals are used. The nuts and caps are designed to be unscrewed or tightened by hand or with the special plastic Service Wrench, V3193-02. If necessary, pliers can be used to

Join our mission.
Make water count.

unscrew to unscrew the nut or cap. Do not use a pipe wrench to tighten nuts or caps. **Do not place screwdriver in slots on caps and/or tap with a hammer.**

3.3.2 Site requirements

- Water pressure – 2,0-6,9 bar
- Water temperature – 0.5-37.7°C
- Current draw is 0.5 amp
- The plug-in transformer is for dry locations only
- The tank should be on a firm level surface



1. The distance between the drain and the water conditioner should be as short as possible.

2. Since salt must be added periodically to the brine tank, it should be in an easily accessible location.

3. It is NOT recommended to install any water treatment unit with less than 3 meters of piping between its outlet and the inlet of a water heater.

CAUTION: To protect the unit in the event of a hot water heater backup, the manufacturer recommends the use of an expansion tank on the outlet side of the unit (see diagram).

4. Do not locate unit where it or its connections (including the drain and overflow lines) will ever be subjected to room temperatures under 0,5°C.

5. Do not subject the tank to any vacuum as this may cause an “implosion” and could result in leaking. If there is a possibility a vacuum could occur, please make provision for a vacuum breaker in the installation.


6. **Inlet/outlet plumbing:** Be sure to install Bypass Valve onto main control valve before beginning plumbing. Make provisions to bypass outside hydrant and cold hard water lines at this time. Install an inlet shutoff valve and plumb to the unit’s bypass valve inlet located at the right rear as you face the unit.

There are a variety of installation fittings available. They are listed under the Installation Fitting Assemblies section of the manual. When assembling the installation fitting package (inlet and outlet), connect the fitting to the plumbing system first and then attach the nut, split ring and “O” Ring. Heat from soldering or solvent cements may damage the nut, split ring or “O” Ring. Solder joints should be cool and solvent cements should be set before installing the nut, split ring and “O” Ring. Avoid getting solder flux, primer, and solvent cement on any part of the “O” Rings, split rings, bypass valve or control valve. If the building’s electrical system is grounded to the plumbing, install a copper grounding strap from the inlet to the outlet pipe. Plumbing must be done in accordance with all applicable local codes.

7. Installing ground: To maintain an electrical ground in metal plumbing of a home’s cold water piping (such as a copper plumbing system), install a ground clamp or jumper wiring.


NOTE: If replacing an existing unit, also replace the ground clamps/wire. If removing a unit, replace the piping with the same type of piping as the original to assure plumbing integrity and grounding.

8. Drain line: First, be sure that the drain can handle the backwash rate of the system. Solder joints near the drain must be done prior to connecting the



drain line flow control fitting. Leave at least 15 cm between the drain line flow control fitting and solder joints. Failure to do this could cause interior damage to the flow control. Install a 1/2" I.D. flexible plastic tube to the Drain Line Assembly or discard the tubing nut and use the 3/4" NPT fitting for rigid pipe (recommended). If the backwash rate is greater than 7 gpm, use a 3/4" drain line. Where the drain line is elevated but empties into a drain below the level of the control valve, form a 18 cm loop at the discharge end of the line so that the bottom of the loop is level with the drain connection on the control valve. This will provide an adequate anti-siphon trap. Piping the drain line overhead < 3 meters is normally not a problem. Be sure adequate pressure is available (2,7-4,1 bar is recommended). Where the drain empties into an overhead sewer line, a sink-type trap must be used with appropriate air gap (see drawing). Run drain tube to its discharge point in accordance with plumbing codes. Pay special attention to codes for air gaps and anti-siphon devices.

Join our mission.
Make water count.



TYPICAL DRAIN LINE INSTALLATIONS

CAUTION: Never insert a drain line into a drain, sewer line, or trap. Always allow an air gap of 1-1/2" or twice the pipe diameter, whichever is greater, between the drain line and the wastewater to prevent the possibility of sewage being back-siphoned into the softener.

9. **Safety brine tank connection:** install the 3/8" O.D. polyethylene tube from the Refill Elbow to the Brine Safety Float valve in the brine tank.

10. **Overflow line connection:** An overflow drain line is recommended where a brine overflow could damage furnishings or the building structure. Your unit is equipped with a brine tank

safety float which greatly reduces the chance of an accidental brine overflow. In the event of a malfunction, however, an overflow line connection will direct the "overflow" to the drain instead of spilling on the floor where it could cause considerable damage. This fitting is an elbow on the side of the brine tank. Attach a length of 1/2" I.D. tubing to fitting and run to drain. Do not elevate overflow line higher than 8 cm below bottom of overflow fitting. Do not "tie" this tube into the drain line of the control valve. Overflow line must be a direct, separate line from overflow fitting to drain, sewer, or tub. Allow an air gap as per the drain line instructions.



Connection at Refill Elbow on the control valve




Connection at Refill Elbow on the control valve
(with optional chlorine generator)



Connection at Brine Safety Float in brine tank

4. PROGRAMMING

4.1 DISPLAY



4.1.1 Display during general operation

When the system is operating, one of six displays may be shown and will alternate with the installing dealer's name and phone number for future service (if set). Pressing NEXT will alternate between the displays.

1. Time of Day Screen: Displays the current time of day, the day of the week, and flow rate.

2. Flow Rate Screen: Displays the current treated water flow rate through the system in Liters Per Minute.

3. Vacation Mode Screen: Allows the system to be "shut down" when there will be no water usage for an extended period of time.


4. Capacity Remaining Screen: Displays the capacity remaining until the system triggers a regeneration.

5. Days to a Regen Screen: Displays the number of days until the system triggers a regeneration. Based on the days override value.

6. Dealer Name Screen: Displays dealer specific name and phone number. This scrolling display will only appear if set by the dealer.

If the system has called for a regeneration that will occur at the preset time of regeneration, the words "REGEN TODAY" will appear on the display.

If a water meter is installed, "LPM" flashes on the display when water is being treated, indicating liters per minute flowing through the system.



Join our mission.
Make water count.

4.1.2 Vacation mode

This feature may be used to “shut down” the system for a period of time by preventing the unit from regenerating. The manufacturer has factory set “OFF” as the default. Turn feature “OFF” or “ON” using the + or – buttons. When turned “ON”, the unit will remain in Vacation Mode until it is exited. There are two ways that a unit can exit Vacation Mode:

Manually: The user may manually exit Vacation Mode by changing the setting from “ON” to “OFF”. Once switched off, a delayed regeneration will queue for that night. Vacation mode may also be manually exited by holding the REGEN button to force an immediate regeneration.


Automatically: The unit will automatically exit Vacation Mode once water usage has resumed. After 190 liters of water is used, the unit will set to resume normal operation and a delayed regeneration will queue for that night.

NOTE: In some instances, if a regeneration has been queued and the unit is taken out of Vacation Mode (manually or automatically), the unit will trigger an immediate regeneration instead of a delayed regeneration. For example, if the unit’s maximum Days Between Regeneration is reached while the unit is in Vacation Mode, an immediate regeneration will trigger as soon as the unit is taken out of Vacation Mode.

CAUTION: Depending on the severity of water conditions and the length of no water usage, it may not be recommended to use this feature. Please contact dealer or manufacturer for more information.

4.1.3 Display during regeneration

Typically, a system is set to regenerate at a time of no water usage. If there is a demand for water when the system is regenerating, untreated water will be delivered. When the system begins to regenerate, the display will include information about the step of the regeneration process and the time remaining for that step to be completed. The system runs through the steps automatically and will reset itself to provide treated water when the regeneration has been completed.



4.1.4 Error message

If the word “ERROR” appears and flashes alternately with the dealer name and phone number, record the ERROR number and contact your servicing dealer promptly. This indicates that the control valve was not able to function properly.



4.2 PROGRAMMING PROCEDURES

4.2.1 Set time of day



Typically, time of day should only need to be set after extended power outages or when daylight saving time begins or ends. If an extended power outage occurs, the time of day will flash on and off indicating that the time should be reset. To set the clock:

Step 1 – Press the **CLOCK** button.

Step 2 – Set the hour of the day using + or – buttons. Press **NEXT** to go to step 3.

Step 3 – Set the minutes using + or – buttons. Press **NEXT** to go to step 4 or **REGEN** to return to previous step.


Step 4 – Set the day of the week using + or – buttons. Press **NEXT** to exit clock setting or **REGEN** to return to previous step.



4.2.2 Programming

The manufacturer has preset the unit so that the capacity between regenerations will be automatically calculated after the hardness is entered. Press **NEXT** to cycle to the next step or **REGEN** to return to the previous step.

Step 1 – Press and hold the **NEXT** and + buttons simultaneously for 3 seconds.



Step 2 – Hardness: Use the + or – buttons to adjust the hardness value.

Depending on how the manufacturer preset this unit, the hardness can be set in °dH, °fH or ppm.

Join our mission.
Make water count.


The hardness value is based on the actual compensated hardness of the water and must be set by an authorized dealer following an on-site water analysis. Adjusting the number will only impact the frequency of regeneration and will not alter or affect the hardness of the water treated by the unit.



Step 3 – Days between regeneration (day override): Use the + or – buttons to adjust the day override. Adjustable from 1-28 days or OFF.

The Day Override value represents the maximum number of days between regenerations. If any number is set (1-28 days), a regeneration will be scheduled for that day if the volumetric capacity has not been met. If OFF is set, the unit will only initiate a regeneration once the volumetric capacity has been met.

Note: This valve has the capability of regenerating up to six times in one day. This can be set by pressing the CLOCK and + buttons simultaneously (on the DAYS BETWEEN REGEN screen). Use the + or – buttons to toggle the correct number of regenerations per day as desired (see example to right). Press NEXT to set the times per day or select “OFF” to return to Days Between Regen. These settings are typically used in commercial settings and should only be set by an authorized dealer.



Step 4 – Regeneration hour: Use the + or – buttons to adjust the time of day the unit will regenerate. The manufacturer has factory set 2:00 as the default setting which is recommended for a normal household.




Step 5 – Regeneration minutes: Use the + or – buttons to set minutes.



Step 6 – Service alarm volume: Use the + or – buttons to schedule a service alarm by number of liters. The range is 100 to 50,000 m³ or OFF. The manufacturer has factory set OFF as the default.

This feature is typically set by the installing dealer to warn the homeowner that service is required after a number of liters have been consumed. If the feature is active, a specific volume amount will appear. For more information regarding how to set service alarms, the installer should consult the master programming guide that corresponds to the unit being installed.


Press the **NEXT** button to advance to the next screen.





Step 7 – Service alarm time: Use the + or – buttons to schedule a service alarm in years. Adjustable in .25 year increments or OFF. The manufacturer has factory set OFF as the default.

This feature is typically set by the installing dealer to warn the homeowner that service is required after an amount of time has passed. If the feature is active, a specific number of days will appear. For more information regarding how to set service alarms, the installer should consult the master programming guide that corresponds to the unit being installed.

Press the **NEXT** button to advance to the next screen.



Step 8 – Alarm buzzer: Use the + or – buttons to turn the alarm ON or OFF. Unit is set to ON by default. Alarm will sound after a regeneration warning the owner of possible valve errors or other issues. This alarm is a short 0.5 second burst every 3 seconds. When alarm buzzer is set to ON, pressing the NEXT button proceeds to the Alarm Start Time screen. This feature allows the installer to choose a time when the owner will be home or awake to hear the alarm.



Join our mission.
Make water count.


BUZZER START TIME: Press the + or – buttons to select the hour when the buzzer should begin sounding. Default setting is 6:00 o'clock.

BUZZER STOP TIME: Press the + or – buttons to select the hour when the buzzer should stop sounding. Default setting is 10:00 o'clock.

Step 9 – Backlight display control:

Use the + or – buttons to turn the backlight setting ON or OFF. If unit is set to OFF, the backlight will turn off after 5 minutes of inactivity.

Press **NEXT** to return to General Display.



5. COMMISSIONING

Flushing of system: To flush the system of any debris and air after installation is complete, please perform the following steps:

1. Rotate bypass handles to the bypass mode (**fig. 2 On page 10**).
2. Turn on inlet water and check for leaks in the newly installed plumbing.
3. Fully open a cold water faucet, preferable at a laundry sink or bathtub without an aerator.
4. Wait two to three minutes or until water runs clear, then turn water off and follow start-up instructions.

Below is the name of each cycle as it appears on the screen with a description of the cycle position. The timing of each cycle will vary depending on the unit size as set from the factory.

Name of cycle	Description
Fill	Brine tank fill
Softening	Soft water brine making
Backwash	Backwash
Regenerant draw dn (down)	Brine draw and slow rinse
Rinse	Fast rinse

The system is now ready for filling with water and for testing.

1. With the softener in the bypass mode (**fig. 2 On page 10**) and the control valve in normal operation where the display shows either the time of day or the capacity remaining, manually add 8 cm of water to the brine tank.

NOTE: if too much water is put into the brine tank during softener start up, it could result in a "salty water" complaint after the first regeneration.

During the first regeneration the unit will draw out the initial volume of brine/regenerant and refill it with the correct preset amount.

2. With the softener in bypass mode, press and hold the **REGEN** button until the motor starts. Release button. The display reads "fill" and the remaining time in this step is counting down. Since the brine tank was already filled in step 1, press **REGEN** again and the display will read SOFTENING 90 (during a full regeneration this will be a 90 minute period for salt to dissolve). Press **REGEN** again to put the valve into "BACKWASH." Once valve has stopped in position, unplug the transformer so that the valve will not cycle to the next position. Open the inlet handle of the bypass valve very slightly allowing water to fill the tank slowly in order to expel air.

Join our mission.

Make water count.

CAUTION: if water flows too rapidly, there will be a loss of media to the drain.

3. When the water is flowing steadily to the drain without the presence of air, slowly open the inlet valve. Restore power and momentarily press the **REGEN** button to advance the control to the “BRINE” position.

4. With the bypass now in diagnostic mode (**Fig. 3 on page 10**), check to verify that water is being drawn from brine tank with no air leaks or bubbles in the brine line. There should be a slow flow to the drain. Disconnect brine line from the safety float valve in the brine tank and check for a vacuum. After proper confirmation, reconnect brine line, making sure to tighten securely.

5. Momentarily press **REGEN** again until the display reads “RINSE.” There should be a rapid flow to the drain. Unplug transformer to keep the valve in the “RINSE” position. Allow to run until steady, clear and without air. While the unit is rinsing, load the brine tank with water softener salt (**Refer to Brine Tank Maintenance and Salt Section**). Restore power.

6. Place bypass valve in the normal operating mode (**Fig. 1 on page 10**) by opening the outlet bypass handle.

Press **REGEN** and the unit will return to the service position with time of day being displayed.

7. Conditioning of media: To flush any remaining debris and air from the system again:

1. Full open a cold water faucet, preferably at a laundry sink or bathtub without an aerator.
2. Wait two to three minutes or until water runs clear, then turn water off.
3. Turn on hot water and check for air, then turn water off after air is discharged.

8. Sanitizing of unit upon installation and after service: At this time, it is advised to sanitize the softener:

1. Open brine tank and remove brine well cover.
2. Pour 30 ml of household bleach into the brine well.

NOTE: Avoid pouring bleach directly onto the safety float components in the brine well.

3. Replace brine well cover. Unit sanitizing will be complete when the first cycle is run and the bleach is flushed from the unit.
9. Check time of day. Start-up is now complete.

6. MAINTENANCE

6.1 ERROR MESSAGE

If the word “ERROR” appears and flashes alternately with the dealer name and phone number, record the ERROR number and contact your servicing dealer promptly. This indicates that the control valve was not able to function properly.




6.2 MANUAL REGENERATION

Sometimes there may be a need to regenerate a unit before the control valve calls for it. This may be needed if a period of heavy water use is anticipated or when the system has been operating without salt.

- To initiate a manual regeneration at the next preset regeneration time, press and release the **REGEN** button. The words “REGEN TODAY” will flash on the display to indicate that the system will regenerate at the scheduled regeneration time (see the Programming Procedures section). If you pressed the **REGEN** button in error, pressing the button again will cancel the command.

- To initiate a manual regeneration immediately, press and hold the REGEN button for three seconds. The system will begin to regenerate immediately. **This command cannot be canceled.**



Once a manual regeneration is initiated, the unit will enter the FILL position. This position allows water to enter the brine tank until it reaches the proper level. Once this position is complete, you will notice a 90 minute SOFTENING position. This 90 minute window allows the salt to dissolve and achieve proper brine strength. During these FILL and SOFTENING positions, you will have softened water available for use. Once the unit advances to the BACKWASH position and subsequent positions thereafter (see Start Up Instructions for regeneration sequence), the unit will deliver water, but it will be untreated.

Join our mission.
Make water count.


IMPORTANT: With the Dry Salt Storage Feature, the brine tank will refill 90 minutes before the actual regeneration occurs. You may experience a small amount of noise for a short period of time at 00:30. (with factory settings) on the night that the regeneration is to occur. This noise is only the brine tank filling and at no time during this process will you be without treated water.

6.3 POWER LOSS AND BATTERY REPLACEMENT

If an extended power outage occurs, the control valve will retain the time of day settings until the board's battery is depleted. Once the battery is depleted, the display will appear dark and absent of any information. If this occurs, following these steps will determine if the problem is a low battery or a board failure.

To determine if the battery is depleted:

1. Remove valve cover. Disconnect power from PC Board at the four pin connector at the bottom of the board.



2. Remove battery. Reference the Parts Breakdown section of this manual for location.

3. Wait five minutes for board to de-energize.

4. With the battery out, re-connect the power supply to the board. The board's display should begin to show information. **This indicates that the board is operating correctly. If the display does not work, call installing dealer for service.**

5. To replace with new battery, unplug transformer from outlet. Install a 3 volt Lithium Coin Cell type 2032 battery, available at most stores. Plug unit back into outlet. **It is important to replace the battery with the valve unplugged to avoid causing a short and potentially ruining the board.**

6. Reset the time of day (see programming procedures) and initiate regeneration (see operating displays and maintenance). **If these procedures do not remedy the problem, please consult the installing dealer for service.**

6.4 BRINE TANK MAINTENANCE AND SALT

Refill the brine tank as necessary, making sure at least 1/3 of the brine tank is full at all times. Without proper salt levels, the water softener may not


operate properly. Because “typical” settings of this water softener include a dry salt storage feature (no water in brine tank between regeneration), the manufacturer recommends the use of solar salt for best results. The brine tank is manufactured for the use of solar, pellets or rock salt. **Do not use block salt.** If pellet or rock salt is used, a cleaning of the brine tank every six months is recommended. If the dry salt storage feature is not being utilized, block salt may be used.

Caution: The manufacturer does NOT recommend the use of any resin cleaners, not placing any resin cleaners into the brine tank. Crystal Right cannot be rinsed with classic resin cleaners, CR Clear Out is to be used. Please use 0.1 litre CR Clear Out per 1 litre Crystal Right by just adding the liquid to the brine tank. During regeneration the Crystal Clear Out will do its work.

6.5 CHECK SALT INDICATOR AND AUDIBLE ALARM

This control valve is equipped with a low salt warning to alert homeowners that the system is operating in a low salt condition. This usually indicates that the salt level in the brine tank is too low to operate properly. If “CHECK SALT” appears on the screen, there will usually be an audible alarm that sounds also (if turned on), alerting you to these conditions.

To turn off alarm: If the audible alarm sounds due to a low salt condition, press any button on the face of the control valve to turn off. If the salt is not added to the brine tank before the next regeneration, the CHECK SALT indicator will alarm again.



Join our mission.
Make water count.

7. TROUBLESHOOTING

PROBLEM	CAUSE	CORRECTION
1. No display on PC board	A. Depleted battery	A. See Operating Display and Maintenance section
	B. Control valve power adapter not plugged into outlet or power cord end not connected to PC board connection	B. Plug power adapter into outlet or connect power cord end to PC board connection
	C. Improper power supply	C. Verify proper voltage is being delivered to PC board
	D. Defective power adapter	D. Replace power adapter
	E. Defective PC board	E. Replace PC board
	F. No power at electric outlet	F. Repair outlet or use working outlet
2. PC board does not display correct time of day	A. Power adapter plugged into electric outlet controlled by light switch	A. Use uninterrupted outlet
	B. Tripped breaker switch and/or tripped GFI	B. Reset breaker switch and/or GFI switch
	C. Power outage	C. Reset time of day. If PC board has battery back up present the battery may be depleted. See front cover and drive assembly drawing for instructions.
	D. Defective PC board	D. Replace PC board
3. Display does not indicate that water is flowing. Refer to user instructions for how the display indicates water is flowing.	A. Bypass valve in bypass position	A. Turn bypass handles to place bypass in service position
	B. Meter is not connected to meter connection on PC board	B. Connect meter to three pin connection labeled METER on PC board
	C. Restricted/stalled meter turbine	C. Remove meter and check for rotation or foreign material
	D. Meter wire not installed securely into three pin connector	D. Verify meter cable wires are installed securely into three pin connector labeled METER
	E. Defective meter	E. Replace meter
	F. Defective PC board	F. Replace PC board

4. Control valve regenerates at wrong time of day	A. Power outage	A. Reset time of day. If PC board has battery back up present the battery may be depleted. See front cover and drive assembly drawing for instructions.
	B. Time of day not set correctly	B. Reset to correct time of day
	C. Time of regeneration set incorrectly	C. Reset regeneration time
	D. Control valve set at "on 0" (immediate regeneration)	D. Check programming setting and reset to NORMAL (for a delayed regen time)
	E. Control valve set at "NORMAL + on 0" (delayed and/or immediate)	E. Check programming setting and reset to NORMAL (for a delayed regen time)
5. Time of day flashes on and off	A. Power outage	A. Reset time of day. If PC board has battery back up present the battery may be depleted. See front cover and drive assembly drawing for instructions.
6. Control valve does not regenerate automatically when the correct button(s) is depressed and held. For timeclock valves the buttons are ▲ & ▼. For all other valves the button is REGEN.	A. Broken drive gear or drive cap assembly	A. Replace drive gear or drive cap assembly
	B. Broken piston rod	B. Replace piston rod
	C. Defective PC board	C. Defective PC board
	D. Cover installed incorrectly	D. Reinstall cover
7. Control valve does not regenerate automatically but does when the correct button(s) is depressed and held. For timeclock valves the buttons are ▲ & ▼. For all other valves the button is REGEN.	A. Bypass valve in bypass position	A. Turn bypass handles to place bypass in service position
	B. Meter is not connected to meter connection on PC board	B. Connect meter to three pin connection labeled METER on PC board
	C. Restricted/stalled meter turbine	C. Remove meter and check for rotation or foreign material
	D. Incorrect programming	D. Check for programming error
	E. Meter wire not installed securely into three pin connector	E. Verify meter cable wires are installed securely into three pin connector labeled METER

Join our mission.
Make water count.

	F. Defective meter	F. Replace meter
	G. Defective PC board	G. Replace PC board
8. Hard or untreated water is being delivered	A. Bypass valve is open or faulty	A. Fully close bypass valve or replace
	B. Media is exhausted due to high water usage	B. Check program settings or diagnostics for abnormal water usage
	C. Meter not registering	C. Remove meter and check for rotation or foreign material
	D. Water quality fluctuation	D. Test water and adjust program values accordingly
	E. No regenerant or low level of regenerant in regenerant tank	E. Add proper regenerant to tank
	F. Control fails to draw in regenerant	F. Refer to Troubleshooting Guide number 12
	G. Insufficient regenerant level in regenerant tank	G. Check refill setting in programming. Check refill flow control for restrictions or debris and clean or replace
	H. Damaged seal/stack assembly	H. Replace seal/stack assembly I. Control valve body type and piston type mix matched I. Verify proper control valve body type and piston type match J. Fouled media bed J. Replace media bed
9. Control valve uses too much regenerant	A. Improper refill setting	A. Check refill setting
	B. Improper program settings	B. Check program setting to make sure they are specific to the water quality and application needs
	C. Control valve regenerates frequently	C. Check for leaking fixtures that may be exhausting capacity or system is undersized
10. Residual regenerant being delivered to service	A. Low water pressure	A. Check incoming water pressure – water pressure must remain at minimum of 1.7 bar
	B. Incorrect, damaged, or restricted injector	B. Replace injector with correct size for the application
	C. Restricted drain line	C. Check drain line for restrictions or debris and clean

11. Excessive water in regenerant tank	A. Improper program settings	A. Check refill setting
	B. Plugged injector	B. Remove injector and replace
	C. Drive cap assembly not tightened in properly	C. Re-tighten the drive cap assembly
	D. Damaged seal/stack assembly	D. Replace seal/stack
	E. Restricted or kinked drain line	E. Check drain line for restrictions or debris and or unkink drain line
	F. Plugged backwash flow controller	F. Remove backwash flow controller and clean or replace
	G. Missing refill flow controller	G. Replace refill flow controller
12. Control valve fails to draw in regenerant	A. Injector is plugged	A. Remove injector and clean or replace
	B. Faulty regenerant piston	B. Replace regenerant piston
	C. Regenerant line connection leak	C. Inspect regenerant line for air leak
	D. Drain line restriction or debris cause excess back pressure	D. Inspect drain line and clean to correct restriction
	E. Drain line too long or too high	E. Shorten length and or height
	F. Low water pressure	F. Check incoming water pressure – water pressure must remain at minimum of 1.7 bar
13. Water running to drain	A. Power outage during regeneration	A. Upon power being restored control will finish the remaining regeneration time. Reset time of day. If PC board has battery back up present the battery may be depleted. See front cover and drive assembly drawing for instructions.
	B. Damaged seal/stack assembly	B. Replace seal/stack assembly
	C. Piston assembly failure	C. Replace piston assembly
	D. Drive cap assembly not tightened in properly	D. Re-tighten the drive cap assembly

Join our mission.
Make water count.

14. E1, Err – 1001, Err – 101 = Control unable to sense motor movement	A. Motor not inserted full to engage pinion, motor wires broken or disconnected	A. Disconnect power, make sure motor is fully engaged, check for broken wires, make sure two pin connector on motor is connected to the two pin connection on the PC board labeled MOTOR. Press NEXT and REGEN buttons for 3 seconds to resynchronize software with piston position or disconnect power supply from PC board for 5 seconds and then reconnect.
	B. PC board not properly snapped into drive bracket	B. Properly snap PC board into drive bracket and then Press NEXT and REGEN buttons for 3 seconds to resynchronize software with piston position or disconnect power supply from PC board for 5 seconds and then reconnect.
	C. Missing reduction gears	C. Replace missing gears
15. E2, Err – 1002, Err – 102 = Control valve motor ran too short and was unable to find the next cycle position and stalled	A. Foreign material is lodged in control valve	A. Open up control valve and pull out piston assembly and seal/stack assembly for inspection. Press NEXT and REGEN buttons for 3 seconds to resynchronize software with piston position or disconnect power supply from PC board for 5 seconds and then reconnect.
	B. Mechanical binding	B. Check piston and seal/stack assembly, check reduction gears, check drive bracket and main drive gear interface. Press NEXT and REGEN buttons for 3 seconds to resynchronize software with piston position or disconnect power supply from PC board for 5 seconds and then reconnect.
	C. Main drive cap too tight	C. Loosen drive cap assembly. Press NEXT and REGEN buttons for 3 seconds to resynchronize software with piston position or disconnect power supply from PC board for 5 seconds and then reconnect.
	D. Improper voltage being delivered to PC board	D. Verify that proper voltage is being supplied. Press NEXT and REGEN buttons for 3 seconds to resynchronize software with piston position or disconnect power supply from PC board for 5 seconds and then reconnect.

16. E3, Err – 1003, Err – 103 = Control valve motor ran too long and was unable to find the next cycle position	A. Motor failure during a regeneration	A. Check motor connections then Press NEXT and REGEN buttons for 3 seconds to resynchronize software with piston position or disconnect power supply from PC board for 5 seconds and then reconnect.
	B. Foreign matter built up on piston and stack assemblies creating friction and drag enough to time out motor	B. Replace piston and stack assemblies. Press NEXT and REGEN buttons for 3 seconds to resynchronize software with piston position or disconnect power supply from PC board for 5 seconds and then reconnect.
	C. Drive bracket not snapped in properly and out enough that reduction gears and drive gear do not interface	C. Snap drive bracket in properly then Press NEXT and REGEN buttons for 3 seconds to resynchronize software with piston position or disconnect power supply from PC board for 5 seconds and then reconnect.
17. E4, Err – 1004, Err – 104 = Control valve motor ran too long and timed out trying to reach home position	A. Drive bracket not snapped in properly and out enough that reduction gears and drive gear do not interface	A. Snap drive bracket in properly then Press NEXT and REGEN buttons for 3 seconds to resynchronize software with piston position or disconnect power supply from PC board for 5 seconds and then reconnect.
18. Err – 1006, Err – 106, Err – 116 = MAV/ SEPS/ NHBP/ AUX MAV valve motor ran too long and unable to find the proper park position Motorized Alternating Valve = MAV Separate Source = SEPS No Hard Water Bypass = NHBP Auxiliary MAV = AUX MAV	A. Control valve programmed for ALT A or B, nHbP, SEPS, or AUX MAV with out having a MAV or NHBP valve attached to operate that function	A. Press NEXT and REGEN buttons for 3 seconds to resynchronize software with piston position or disconnect power supply from PC board for 5 seconds and then reconnect. Then reprogram valve to proper setting
	B. MAV/NHBP motor wire not connected to PC board	B. Connect MAV/NHBP motor to PC board two pin connection labeled DRIVE. Press NEXT and REGEN buttons for 3 seconds to resynchronize software with piston position or disconnect power supply from PC board for 5 seconds and then reconnect.


Join our mission.
Make water count.

	C. MAV/NHBP motor not fully engaged with reduction gears	C. Properly insert motor into casing, do not force into casing Press NEXT and REGEN buttons for 3 seconds to resynchronize software with piston position or disconnect power supply from PC board for 5 seconds and then reconnect.
	D. Foreign matter built up on piston and stack assemblies creating friction and drag enough to time out motor	D. Replace piston and stack assemblies. Press NEXT and REGEN buttons for 3 seconds to resynchronize software with piston position or disconnect power supply from PC board for 5 seconds and then reconnect.
19. Err – 1007, Err – 107, Err – 117 = MAV/ SEPS/ NHBP/AUX MAV valve motor ran too short (stalled) while looking for proper park position Motorized Alternating Valve = MAV Separate Source = SEPS No Hard Water Bypass = NHBP Auxiliary MAV = AUX MAV	A. Foreign material is lodged in MAV/NHBP valve	A. Open up MAV/NHBP valve and check piston and seal/ stack assembly for foreign material. Press NEXT and REGEN buttons for 3 seconds to resynchronize software with piston position or disconnect power supply from PC board for 5 seconds and then reconnect.
	B. Mechanical binding	B. Check piston and seal/stack assembly, check reduction gears, drive gear interface, and check MAV/NHBP black drive pinion on motor for being jammed into motor body. Press NEXT and REGEN buttons for 3 seconds to resynchronize software with piston position or disconnect power supply from PC board for 5 seconds and then reconnect.
20. Err – 109	A. Invalid motor state detected	A. Replace PC board
21. Err – 201	A. Invalid regeneration cycle step detected	A. Replace PC board
22. Err – 204 = Leak detected	A. Occurs when dP input is active for “ALARM” and the input is closed. The alarm buzzer will activate and the screen will display the error.	A. Check for low flow leak. Press NEXT and REGEN buttons for 3 seconds to resynchronize software with piston position or disconnect power supply from PC Board for 5 seconds and then reconnect to clear error.
23. Err – 400* Memory Errors*(All 400 errors pertain to memory related errors)	A. Depleted Battery	A. See Operating Display and Maintenance section
	B. Defective PC Board	B. Replace PC board

8. REPLACEMENT PARTS & INSTALLATION FITTINGS

8.1 FRONT COVER AND DRIVE ASSEMBLY


Item No.	Part No.	Description	Qty.
1	CV3367-01-A	Black cover	1
	CV3367-01-WR-A	Grey cover	1
2	V3107-1	Motor	1
3	V3002A	Drive assembly (Includes #5 and #6)	-
4	CV3502WD-03	PC board Evolve	1
5	V3110	Drive gear, 12 x 36	3
6	V3109	Drive gear cover	1
not shown	CV3526EU	EU Transformer, 220/15VDC	1
	V3684-WR-GLD	Optional weather cover	1



Join our mission.
Make water count.



8.2 PISTON ASSEMBLY

Item No.	Part No.	Description	Qty.
1	V3005-02	1" spacer stack assembly	1
	V3430-01	1.25" spacer stack assembly	1
	V3004	Drive cap assembly	1
3	V3135	O-ring 228	1
4	V3011	1" piston assembly downflow	1
	V3011-01	1" piston assembly upflow	1
	V3407	1.25" piston assembly downflow	1
5	V3174	Regenerant piston	1
6	V3180	O-ring 337	1
7	V3105	O-ring 215	1
	V3358	O-ring 219, 1.25" distributor	1
8	CV3556	Screw, 1/4-20x1-1/2 18-8SS	1
9	CCI-00318337	Nut, 1/4-20 HEX 18-8SS	1
10	CV3016	QC2 clamp assembly (includes screw & nut)	1
11	V3452	O-ring 230	1
12	CV3015	WS1 QC2 tank adapter assembly (includes O-rings)	1
13	CV3001-04	1" body assembly downflow	1
	CV3020	1.25" body assembly downflow	1
14	CV3368	Drive backplate	1



8.3 BYPASS VALVE

Item No.	Part No.	Description	Qty.
1	V3006	Bypass assembly	1
2	V3147	Bypass handles	2




8.4 REFILL PORT ASSEMBLY

Item No.	Part No.	Description	Qty.
1	V4144	3/8" Elbow, Parker fitting	1
2	V3163	O-ring 019	1
3	V3195-01	Refill port plug assembly	1
4	H4615	Elbow locking clip	1
5	CV3395	Chlorine Generator (Black)	1

8.5 SERVICE WRENCH - V3193-02

Although no tools are necessary to assemble or disassemble the valve, the Service Wrench, (shown in various positions on the valve) is available to aid in assembly or disassembly.




Join our mission.
Make water count.

8.6 INJECTOR ASSEMBLIES



Item No.	Part No.	Description	Qty.
1	V3176	Injector cap	1
2	V3152	O-ring 135	1
3	V3177-01	Injector screen	1
4	V3010-IZ	Injector assembly plug	1
5	V3010-1A	A injector assembly, BLACK	1
	V3010-1B	B injector assembly, BROWN	
	V3010-1C	C injector assembly, VIOLET	
	V3010-1D	D injector assembly, RED	
	V3010-1E	E injector assembly, WHITE	
	V3010-1F	F injector assembly, BLUE	
	V3010-1G	G injector assembly, YELLOW	
	V3010-1H	H injector assembly, GREEN	
	V3010-1I	I injector assembly, ORANGE	
	V3010-1J	J injector assembly, LIGHT BLUE	
	V3010-1K	K injector assembly, LIGHT GREEN	
not shown	V3170	O-ring 011, lower	*
not shown	V3171	O-ring 013, upper	*

*The injector plug and the injector each use one lower and one upper o-ring



8.7 WATER METER AND METER PLUG


Item No.	Part No.	Description	Qty.
1	V3151	Nut, 1" QC	1
2	V3003	Meter assembly, includes items 3 & 4	1
3	V3118-01	Turbine assembly	1
4	V3105	O-ring 215	1
5	V3003-01	Meter plug assembly	1



8.8 DRAIN LINE ASSEMBLY 3/4"


Item No.	Part No.	Description	Qty.
1	H4615	Elbow locking clip	1
2	PKP10TS8-BULK	Optional insert, 5/8" tube	1
3	V3192	Optional nut, 3/4" drain elbow	1
4	V3158-02	Drain elbow, 3/4" NPT with O-ring	1
5	V3163	O-ring 019	1
6	V3159-01	DLFC retainer assembly	1
7	V3162-007	0.7 DLFC for 3/4" elbow	1
	V3162-010	1.0 DLFC for 3/4" elbow	
	V3162-013	1.3 DLFC for 3/4" elbow	
	V3162-017	1.7 DLFC for 3/4" elbow	
	V3162-022	2.2 DLFC for 3/4" elbow	
	V3162-027	2.7 DLFC for 3/4" elbow	
	V3162-032	3.2 DLFC for 3/4" elbow	
	V3162-042	4.2 DLFC for 3/4" elbow	
	V3162-053	5.3 DLFC for 3/4" elbow	
	V3162-065	6.5 DLFC for 3/4" elbow	
	V3162-075	7.5 DLFC for 3/4" elbow	
8	V3331	Drain elbow and retainer assembly	1

Items 2 and 3, nut and insert are only used with 1/2" I.D. by 5/8" O.D. polytubing. For other piping material, the 3/4" NPT is used.



8.9 DRAIN LINE ASSEMBLY 1"

Item No.	Part No.	Description	Qty.
1	H4615	Elbow locking clip	1
2	V3166	Drain FTG body 1	1
	V3166-01	FTG flow control body 1	1
3	V3167	Drain FTG adapter 1	1
4	V3163	O-ring 0191	1
5	V3150	Split ring1	1
6	V3151	Nut 1" QC1	1
7	V3105	O-ring 215	1
8	V3190-090	9.0 gpm DLFC for 1" elbow	One DLFC must be used if 1" fitting is used
	V3190-100	10.0 gpm DLFC for 1" elbow	
	V3190-110	11.0 gpm DLFC for 1" elbow	
	V3190-130	13.0 gpm DLFC for 1" elbow	
	V3190-150	15.0 gpm DLFC for 1" elbow	
	V3190-170	17.0 gpm DLFC for 1" elbow	
	V3190-200	20.0 gpm DLFC for 1" elbow	
	V3190-250	25.0 gpm DLFC for 1" elbow	
9	V3008-04	FTG Drain 1" Strt No/Sil	1




Join our mission.
Make water count.

8.10 BRINE TANK ASSEMBLY


Item No.	Part No.	Description	Qty.
1	G2191-84	Brine tank cover, injection molded WR	1
	G2180	Brine tank cover, standard	1
2	H1095-01	Optional 18" diameter salt grid	1
	H1080	Optional 24" diameter salt grid	1
3	G21833CB1C00	18" x 33" brine tank, black	1
	G21840CB1C00	18" x 40" brine tank, black	1
	G22441CB1C00	24" x 41" brine tank, black	1
4	H1030-29S	4" x 29" slotted brine well (18 x 33 BT)	1
	H1030-36S	4" x 36" slotted brine well (18 x 40, 24 x 40 BT's)	1
5	H1018	2 piece overflow set	1
6	H4500-48	474 air check assembly, 1/2" x 48"	1
7	H4620	474 float assembly, 7"	1
8	H4600-50	474 safety brine valve w/ 5 gpm glow control	1
9	H7016	Cap 4" brine well	1
10	H4626	Nut safety brine valve stand off	1
Assemblies			
11	H4700-29WR-1	.5 gpm safety float assembly, 18" x 33"	1
	H4700-36.5WR-1	.5 gpm safety float assembly, 18" x 40"	1

For units with separate brine tank.



8.11 SAFETY FLOAT BRINE ELBOW


Item No.	Part No.	Description	Qty.
1	CH4651-050	474 .5 gpm flow control	1
2	CV3163	O-Ring 019	1
3	CV4144	3/8" elbow cap, Parker fitting	1
	CH4612	1/2" elbow cap	1
4	CH4615	Elbow locking clip	1



Order No: V3007-06

Description WS1 Fitting 1" Plastic Male BSPT Assembly


Drawing No.	Order No.	Description	Quantity
1	V3151	WS1 NUT 1" QUICK CONNECT	2
2	V3150	WS1 SPLIT RING	2
3	V3105	O-RING 215	2
4	V3316	WS1 FITTING 1" PLASTIC MALE BSPT	2



Order No: V3007-08

Description WS1 Fitting 1-1/4" Plastic Male BSPT Assembly


Drawing No.	Order No.	Description	Quantity
1	V3151	WS1 NUT 1" QUICK CONNECT	2
2	V3150	WS1 SPLIT RING	2
3	V3105	O-RING 215	2
4	V3361	WS1 FITTING 1-1/4" PLASTIC MALE BSPT	2



Order No: V3007-12LF

Description WS1 Fitting 3/4" Brass SharkBite Assembly LF


Drawing No.	Order No.	Description	Quantity
1	V3151	WS1 NUT 1" QUICK CONNECT	2
2	V3150	WS1 SPLIT RING	2
3	V3105	O-RING 215	2
4	V3628-LF	WS1 FTG 3/4 Brass SharkBite LF	2



Order No: V3007-07

Description WS1 Fitting 1-1/4" & 1-1/2" PWC Solvent Assembly


Drawing No.	Order No.	Description	Quantity
1	V3151	WS1 NUT 1" QUICK CONNECT	2
2	V3150	WS1 SPLIT RING	2
3	V3105	O-RING 215	2
4	V3352	WS1 FITTING 1-1/4" & 1-1/2" PVC Solvent	2



Order No: V3007-09LF

Description WS1 Fitting 1-1/4" & 1-1/2" Brass Sweat Assembly LF


Drawing No.	Order No.	Description	Quantity
1	V3151	WS1 NUT 1" QUICK CONNECT	2
2	V3150	WS1 SPLIT RING	2
3	V3105	O-RING 215	2
4	V3375-LF	WS1 FITTING 1-1/4" & 1-1/2" Brass Sweat LF	2




Order No: V3007-13LF

Description WS1 Fitting 1" Brass SharkBite Assembly LF

Drawing No.	Order No.	Description	Quantity
1	V3151	WS1 NUT 1" QUICK CONNECT	2
2	V3150	WS1 SPLIT RING	2
3	V3105	O-RING 215	2
4	V3629-LF	WS1 FITTING 1" Brass SharkBite LF	2




Join our mission.
Make water count.




Order No: V3007-14
Description WS1 Fitting 3/4\"

Drawing No.	Order No.	Description	Quantity
1	V3151	WS1 NUT 1\" QUICK CONNECT	2
2	V3150	WS1 SPLIT RING	2
3	V3105	O-RING 215	2
4	V3594	WS1 FITTING 3/4\" PLASTIC MALE BSPT	2




Order No: V3007-15
Description WS1 FTG 3/4 JG QC 90 ASY

Drawing No.	Order No.	Description	Quantity
1	V3151	WS1 NUT 1\" QUICK CONNECT	2
2	V3150	WS1 SPLIT RING	2
3	V3105	O-RING 215	2
4	V3790	WS1 Elbow 3/4 QC W/ STEM	2





Order No: V3007-16
Description WS1 Fitting 1\"

Drawing No.	Order No.	Description	Quantity
1	V3151	WS1 NUT 1\" QUICK CONNECT	2
2	V3150	WS1 SPLIT RING	2
3	V3105	O-RING 215	2
4	V3797	WS1 FTG 1\" Male BSPT Elbow	2



Order No: V3007-17
Description WS1 FTG 1\"

Drawing No.	Order No.	Description	Quantity
1	V3151	WS1 NUT 1\" QUICK CONNECT	2
2	V3150	WS1 SPLIT RING	2
3	V3105	O-RING 215	2
4	V4045	WS1 FTG 1 inch QC	2



9. CERTIFICATION



DECLARATION OF CONFORMITY DÉCLARATION DE CONFORMITÉ OVEREENKOMSTIGHEIDSVKLAARING DECLARACIÓN DE CONFORMIDAD DICHIARAZIONE DI CONFORMITÀ KONFORMITÄTSEKLRÄRUNG

Suko N.V.,
manufacturer of the following unit, specified in the Technical Sheets,
fabricant de l'appareil suivant, indiqué dans les fiches techniques ,
fabrikant van de volgende eenheid, gespecificeerd in de technische fiches ,
fabricante de la unidad siguiente, especificada en las fichas técnicas ,
produttore delle seguenti unità, specificato nelle schede tecniche ,
Hersteller der folgenden Einheit, in den technischen Datenblättern angegeben,

Evolve Series Crystal Right Filters

declares that this unit complies with the requirements of the directives :
déclare que cet appareil est conforme aux exigences des directives :
verklaart dat dit apparaat voldoet aan de vereisten van de richtlijnen :
declara que esta unidad cumple con los requisitos de las directivas :
dichiara che questo apparecchio è conforme ai requisiti delle direttive :
erklärt, dass dieses Gerät den Anforderungen der Richtlinien :

- | | |
|-------------------------------------|-------------------------------|
| ☐ 2014/30/EU | Electromagnetic Compatibility |
| ☐ 2014/35/EU | Low Voltage Directive |
| ☐ 2006/42/EC | Machinery Directive |
| ☐ 2011/65/EU | ROHS directive |
| ☐ 2014/68/EU | Pressure Equipment Directive |

Waregem, 05-08-2020
Anton Lapitski
General Manager


Join our mission.
Make water count.

10. QUICK REFERENCE GUIDE

10.1 GENERAL OPERATION

When the system is operating, one of six displays will be shown:

1. time of day/lpm
2. flow rate
3. vacation mode
4. capacity remaining
5. days to a regen
6. dealer name and phone number




Pressing **NEXT** will toggle between the six choices

10.2 TO SET TIME OF DAY

In the event of a prolonged power outage, time of day flashes, indicating that this needs to be reset. All other information will be stored in memory no matter how long the power outage.


1. Accessed by pressing **SET** **CLOCK**
2. Adjust hours with **+** and **-** buttons
3. Press **NEXT**
4. Adjust minutes with **+** and **-** buttons
5. Press **NEXT**
6. Adjust current day with **+** and **-** buttons
7. Press **NEXT** to complete and return to normal operation



10.3 MANUAL REGENERATION

NOTE: If brine tank does not contain salt, fill with salt and wait at least 90 minutes before regeneration. If you need to initiate a manual regeneration, either immediately, or the same night at the preprogrammed time for regeneration (typically at 02:00 o'clock), complete the following steps.

For Immediate Regeneration: Press and hold **REGEN** until valve motor starts (typically 3 seconds)




For Regeneration the same night:

Press and release **REGEN** (notice that flashing "REGEN TODAY" appears).



10.4 ERROR

If the display toggles between "Error" and an error code (i.e. a number), call a service technician and report the error code.



10.5 BYPASS VALVE OPERATION

To shut off water to the system, position arrow handles as shown in the bypass operation diagram below. If your valve doesn't look like the diagram below, contact your service technician for instructions on how to shut off water.


10.6 ADJUST HARDNESS, DAYS BETWEEN REGENERATION, TIME OF REGENERATION AND ALARM BUZZER

For initial set-up or to make adjustments, please complete the following steps

1. Accessed by pressing **NEXT** and **+** button simultaneously
2. Adjust hardness using **+** and **—** buttons
3. Press **NEXT**
4. Adjust days between regenerations using **+** and **—** buttons
5. Press **NEXT**
6. Adjust time of regeneration hour with **+** and **—** buttons
7. Press **NEXT**
8. Adjust time of regeneration minutes with **+** and **—** buttons
9. Press **NEXT**
10. Turn service alarm time ON with **+** and **—** buttons. Default is OFF
11. Press **NEXT** twice

Join our mission.
Make water count.

12. Turn service alarm volume ON with **+** and **-** buttons Default is OFF
13. Press **NEXT** twice
14. Turn alarm buzzer ON or OFF with **+** and **-** buttons
15. Press **NEXT**
16. Adjust alarm buzzer start time with **+** and **-** buttons
17. Press **NEXT**
18. Adjust alarm buzzer end time with **+** and **-** buttons
19. Press **NEXT**
20. Turn display backlight ON or OFF with **+** and **-** buttons Default is ON
21. Press **NEXT** to complete and return to normal operation



Evolve Crystal Right