

Scan the QR code to consult
the manual in other languages.




HOME WATER KIT

INLINE INSTALLATION & CARTRIDGE REPLACEMENT

INCLUDED IN THIS KIT

- Cartridge head
- Filter cartridge
- Flexibles



TEMPERATURE

Min - Max
4 °C – 30 °C



WORKING PRESSURE

Min - Max
2 bar – 6 bar




HOME WATER KIT

INLINE INSTALLATION


1

Close the water inlet and open the outlet faucet to drain all the water out of the piping system.



2

Disconnect the faucet tubes and install the delivered flexibles on the cold water line faucet tubes. Take care of the remaining water that could come from those tubes. Use teflon tape for the connections.




CAUTION: Do not connect the filter on the hot water line.

3


Mount the delivered head onto the wall. Make sure to have enough available space for the installation of the cartridge.

NOTE: By default, the In and Out of the head are on the right side. Depending on your installation, you can detach the top piece by unscrewing the 4 screws on the bottom and turn it around to have the IN and OUT on the left side.




4

Connect the delivered flexibles to the head, push the stem of the flexible firmly in the pushfit connection. Please pay attention to the correct connection to the inlet and the outlet.




5

Remove the cap seal from the delivered cartridge and moisten the O-rings with water; push the cartridge up into the Head and turn it a ¼ turn to the right.




6

When your Home Water Kit is installed, gently open the water inlet valve and make sure to rinse the cartridge for 5 minutes. Do not take any water during this time. During rinsing the water may contain black carbon particles. Keep rinsing until there are no particles left and the water is clear.



7

After rinsing, close your outlet faucet and double-check your installation for any leakages.




HOME WATER KIT

CARTRIDGE REPLACEMENT


1

Close the water inlet valve and open the outlet faucet.




2

Turn the cartridge a ¼ turn to the left and pull it out.




3

Remove the cap seal and moisten the o-rings with water: push the cartridge up and turn it a ¼ turn to the right.



4

Gently open the water inlet valve and make sure to rinse the cartridge for 5 minutes. Do not take any water during this time. During rinsing the water can obtain black carbon particles. Keep rinsing until there are no particles left and the water is clear.



5

After rinsing, close your outlet faucet and double-check your installation for any leakages.

